


Setting up a projector to play DVDs or VHS tapes

Unlike TVs, projectors I have used do not have internal speakers or audio jacks for speakers. The speakers must be attached to the DVD player or VCR through their Audio Out jacks.

I have a set of small Bose speakers, which are excellent.



THE BASIC IDEA

- ... Change the Input on the projector to Video
- ... From your DVD player or VCR, connect the Video Out to the projector's Video In
- ... From your DVD player or VCR, connect the Audio Out to the speaker's Audio In
- ... This requires 2 separate cables, even if they are both generic AV cables
- ... Beware of devices requiring something other than the standard RCA plugs on your AV cables